


Electrical Locations



- A** 12 Volt DC Breaker Panel under passenger seat
- B** Coach Disconnect Switch at the left floor level beneath fire extinguisher
- C** Water Pump under floor panel beneath stove
- D** 120 Volt AC Circuit Breaker behind panel near floor
- E** Charger behind 120 Volt AC circuit breaker Remove Drawers below coat closet
- F** Transfer Switch, under passenger bed
- G** Truma GFI behind vent at floor level
- H** 12 Volt DC Fuse Panel behind panel near floor
- I** Truma Heater beneath drivers bed



A



B



C



D



E

Progressive Dynamics Series 9200




F

TRC model 41300



G

GFI Ground Fault Interrupter



H

Precision Circuits Inc. 12 Volt DC Fuse panel Diagnostic Center



I

Truma RV Heater